



 **Cancellazione di tutti i codici in memoria**

1. Entro 15 secondi dal rilascio del pulsante d'emergenza (1), **premere 10 volte il pulsante (3)** posizionato sul retro del radiocomando: ad ogni pressione il buzzer della scheda radio emette un suono intermittente.
2. Alla decima pressione **mantenere premuto il pulsante (3) per 5 secondi**, il buzzer della scheda radio emette un suono intermittente veloce per poi emettere un suono continuo.
3. Rilasciare il pulsante ed eseguire la procedura di programmazione del radiocomando.

 **Programmazione del radiocomando**

1. Entro 10 secondi dal rilascio del pulsante d'emergenza (1), premere e **mantenere premuto per 2 secondi** il pulsante (3) posizionato sul retro del radiocomando. In questo modo si avvia la modalità di associazione di un codice radio: il buzzer della scheda emette un suono continuo.
2. Premere 3 volte il tasto (2) del radiocomando: il buzzer della scheda radio emette un suono ad intermittenza per confermare la corretta associazione del codice radio.
3. Attendere alcuni secondi e verificare il corretto funzionamento del radiocomando testando il motore nei due sensi di marcia della copertura (apertura e chiusura).

In caso d'errore, o non funzionamento dei cicli, contattare il servizio di assistenza post-vendita.

 **Deletion of all codes in memory**

1. Within 15 seconds after having released the emergency button (1), **press the button (3)** on the rear of the remote control **10 times**: at each pressure the receiver card buzzer emits an intermittent sound.
2. When pressing the button at the tenth time, **keep the button (3) pressed for 5 seconds** and the receiver card buzzer emits a fast-intermittent sound and afterwards a continuous sound.
3. Release the button and carry out the remote-control programming procedure.

 **Remote control programming**

1. Within 10 seconds after having released the emergency button (1), **press and keep down the button (3)** on the rear of the remote control **for 2 seconds**. In this way you start the association mode of a radio code: the receiver card's buzzer emits a continuous sound.
2. Press the button (2) on the remote control: the receiver card's buzzer emits an intermittent sound to confirm that the association of the radio code has been successfully done.
3. Wait a few seconds and check the correct operation mode of the remote control by testing the motor in both opening and closing function of the covering system.

In case of failure of the cycles or any error, please contact the After-Sales Service.